



IMPORTANT:

READ BEFORE INSTALLATION

When installing panels with **DripX™** Condensation Control, it is critical that panels and/or trim are properly prepared at key junctures -- such as eaves, endlaps and ridge caps -- to prevent moisture from wicking from the outside.

HOW TO PROPERLY PREP PANELS AND TRIM:

For all points of exposure to outside environment, a recommended length of the panel should be prepared, such as:

- Eave overhang (overhang + 1")*
- Panel to panel endlaps (length of lap minus ¼")
recommended to avoid endlaps and run panels continuously from eave to ridge
- Ridge cap laps (length of lap minus ¼")

1. Lay/stack panels with **DripX™** Condensation Control material facing up and recommended length of each panel exposed.

2. Using a heat gun set at 1200°F, move the gun along the exposed end portion of each panel, heating/fusing the fibers of the **DripX™**.

- Hold the heat gun approximately 1" away from the **DripX™** material.
- Keep the heat gun in constant motion to avoid overheating one spot, potentially damaging the panel's finish.
- Do not completely melt the **DripX™** material.
- If at lap, do not extend fusing past the lap.

3. Allow panels to cool.

4. Install panels as normal.

**Eaves may be prepared after installation of panels.*

Failure to properly prepare panels may result in the DripX™ material attracting water from outside, resulting in possible leaks, mold and/or mildew -- ultimately voiding your panel warranty.

**CONTACT YOUR SALESPERSON FOR DETAILS
REGARDING PRICING AND AVAILABILITY.**



Lowell, AR	Michigan City, IN	Cedar Hill, TX
800-356-2733	800-638-2565	800-210-8305
Mount Airy, NC	Jasper, AL	
877-813-2111	866-270-6608	